














150



							
A	B	C	D	E	F	H	O
12	16	1	30-40	4	4	44	4



A vertical ruler on the left side of the page indicates measurements in centimeters, ranging from 0 to 10. To the right of the ruler are icons for various tools: a hammer, a screwdriver, a utility knife, and a pencil. A warning icon shows a hand holding a screwdriver, with a red 'X' over it, indicating that the screwdriver should not be used to tighten the screws.



150

